



Installation & Operating Instructions

READ THESE INSTRUCTIONS BEFORE OPERATION

KEEP ORIGINAL PACKAGING: All returns need to be in the original packaging in order to avoid product damage during shipping. Any damage to products not in their original packaging will not be covered under warranty.

SAFETY FIRST!

Failure to observe the following safety warnings may result in serious injury. In addition, failure to observe these safety warnings will result in a waiver of all liabilities and will void all warranties.

INSTRUCTIONS FOR OPERATION:

1. Remove fixture from box along with all accessories.
2. Make sure on/off switches are in the off position.
3. The fixture is now ready to be hung – mount to ceiling studs or other secure location. Use V-hangers and supplied BRACKET to hang the fixture. DO NOT use the power cord as a means of support.
4. Plug in the fixture. Excess cord should be kept out of the work space.
5. Turn switch(es) to the on position.
6. These fixtures have a daisy chain feature. See chart below for maximum number of AgroLED® SUN® fixtures that can be daisy chained together (do not exceed 12 amps). Plugging more than the specified number of fixtures together is a safety hazard & will void the warranty.

ITEM NUMBER	PRODUCT NAME	MAXIMUM DAISY CHAIN
960475	AgroLED® Sun® 48" White LED 5500° K	5
960474	AgroLED® Sun® 24" White LED 5500° K	10
960473	AgroLED® Sun® 18" White LED 5500° K	10
960478	AgroLED® Sun® SUPREME 48" White LED 5500° K	5
960477	AgroLED® Sun® SUPREME 24" White LED 5500° K	10
960476	AgroLED® Sun® SUPREME 18" White LED 5500° K	10

WARNING:

- Make sure power cord is connected properly.
- Disconnect power before relamping.
- **DO NOT** hang by power or lamp cord.
- **DO NOT** make contact with the interior of the socket while power is on.
- **DO NOT** operate light systems in wet locations.
- **DO NOT** plug system into supply voltage other than what is designated on fixture.
- **DO NOT** attempt to rewire or reconfigure your system, it will void warranty and could cause serious safety hazards (i.e. power cord, lamp cord, lamp socket).

Keep away from children.

TROUBLESHOOTING:

If your fixture does not work

1. CHECK YOUR ELECTRICAL SOURCE: Make sure the unit is plugged in properly and that the breaker is not tripped or fuse blown.

THIS PRODUCT MUST BE INSTALLED IN ACCORDANCE WITH THE APPLICABLE INSTALLATION CODE BY A PERSON FAMILIAR WITH THE CONSTRUCTION AND OPERATION OF THE PRODUCT AND THE HAZARDS INVOLVED.

CE PRODUIT ÊTRE INSTALLÉ SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAÎT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHÉRENTS.



WARRANTY SERVICE:

PLEASE READ WARRANTY INFORMATION FIRST

If the light does not work after troubleshooting, please return the light to the dealer where it was purchased. The dealer will evaluate and test the light and its components. The dealer may be able to repair the light on site. If the dealer is unable to repair the light, they will return it to us for factory repair. Many dealers will provide loaner fixtures for use during the repair period (usually not more than 7-10 days).

To locate dealers within the United States: www.HawthorneGC.com. To locate dealers within Canada: www.HawthorneGC.ca. and click "AUTHORIZED DEALERS". If there are no dealers in your area, please contact us directly for technical support. If we cannot help you resolve the problem over the phone and if the unit is still in warranty, we will issue you an RMA # (return merchandise authorization number) authorizing you to return the system to us for factory reconditioning. You will be asked to provide an email address or fax number to receive the RMA form. The completed RMA form must be included in the packaging when returning your AgroLED® unit. Also please write the RMA # on the outside of the box.

Please package the light carefully in its original packaging. We are not responsible for fixtures damaged during shipment.

The light will be repaired within 48 hours of receipt and returned via UPS Ground. If the unit cannot be repaired, a replacement will be sent. If there are no identical units available, a comparable fixture will be substituted.

IMPORTANT:

PROOF OF PURCHASE REQUIRED FOR RETURNS

AGROLED® SUN® STRIP LIGHT FIXTURE:

3 Year Warranty Returning Units: *Please contact your retail store for returns.*

WARRANTY INFORMATION: The Hawthorne Gardening Company warrants to the original purchaser of this product against defects in material and workmanship under normal use for 3 years on AgroLED® SUN® Strip Light Fixture. During the warranty period, The Hawthorne Gardening Company will, at our option, and without charge, repair or replace this product if the unit or any of its components fail or malfunction. This warranty is expressly in lieu of all other warranties, expressed or implied, including the warranties of merchantability and fitness for use and of all other obligations or liabilities on the part of the seller. This warranty shall not apply to this product or any part thereof which has been damaged by accident, abuse, misuse, modification, negligence, alteration or misapplication. The Hawthorne Gardening Company makes no warranty whatsoever in respect to accessories or parts not supplied by The Hawthorne Gardening Company. This warranty shall apply only to the United States, including Alaska, Hawaii, territories of the United States and Canada.



HAWTHORNE GARDENING

CO

Manufactured for Hawthorne Hydroponics LLC,
a subsidiary of The Hawthorne Gardening Company
3204 NW 38th Circle, Vancouver, WA 98660 | ©2018

HawthorneGC.com | Canada: HawthorneGC.ca

